

Kore Angle Jack – Identification and Replacement

Parts and Tools Needed:

1. (2) 3/4 " wrenches
2. 2x4 length, 83" long

Procedure:

1. First, in order to get the correct replacement jack identify the correct jack: there are three versions depending on the age of your Kore:
 - A. The top tube is 2.5" diameter
 - B. The top tube is 28" long (the tube with three holes in it) and the top hole is @ 7" from the top end.
 - C. The top tube is 22" long and the top hole is @ 6" from the top end
2. Order the correct jack from Brewer Fitness – usually a 2-5 days to shipment.
3. Using the instructions in the sheet on changing angle with a 2x4 brace, install the brace on the side on the defective jack and replace the jack.
4. Depending on the circumstance, there may be a return label in the box so that you can return the defective jack to Brewer Fitness.

Figures:

